

## Superwinch H10P Major Service Kit

Part No	<u>Description</u>	<b>Quantity</b>
Α	TC20x30x7 Oil Seal 2nd Stage Planet	1
В	HK2020 bearing INA (Germany) 2nd stage	1
10051	Thrust Washer 2nd Stage Carrier	1
10006	Thust Washer Sun Gearing	2
4.32.4562083	Oil Seal TC45x62x8 NBR Front Housing	1
4.22.140161123	V Sealing Ring VA-140	2
10064	Gasket Front housing	1
4.10.4550203	Bush Bearing MB4520DU	1
10063	Gasket Bearing Plate/Brake housing	2
10049	Drum Support Bearing	2
HFL2530	Sprag Bearing Brake INA (Germany)	1
4.31.1403030403	Springs, Brake	6
4.130250471	Roller Bearing (6005NR) Drive Support	1
4.36.0601022	Cap Head Sealing Screw	2





## **Tools Required For Servicing H10P**

Spanner/Socket 16mm & 17mm Allen Key 6mm Allen key 10mm 2 x M5x0.8 pitch x 40mm screw 2 x Nut M5 & flat washer

## Note:

Gearbox requires 500ml gear oil Please refer to owner's manual for suitable recommendations

