



Superwinch H10P Major Service Kit

<u>Part No</u>	<u>Description</u>	<u>Quantity</u>
A	TC20x30x7 Oil Seal 2nd Stage Planet	1
B	HK2020 bearing INA (Germany) 2nd stage	1
10051	Thrust Washer 2nd Stage Carrier	1
10006	Thrust Washer Sun Gearing	2
4.32.4562083	Oil Seal TC45x62x8 NBR Front Housing	1
4.22.140161123	V Sealing Ring VA-140	2
10064	Gasket Front housing	1
4.10.4550203	Bush Bearing MB4520DU	1
10063	Gasket Bearing Plate/Brake housing	2
10049	Drum Support Bearing	2
HFL2530	Sprag Bearing Brake INA (Germany)	1
4.31.1403030403	Springs, Brake	6
4.130250471	Roller Bearing (6005NR) Drive Support	1
4.36.0601022	Cap Head Sealing Screw	2



Tools Required For Servicing H10P

Spanner/Socket 16mm & 17mm
 Allen Key 6mm
 Allen key 10mm
 2 x M5x0.8 pitch x 40mm screw
 2 x Nut M5 & flat washer

Note:

Gearbox requires 500ml gear oil
 Please refer to owner's manual for suitable recommendations

H10P Owner's Manual



H10P Exploded View

